

REPLACEMENT CASE DISASSEMBLY AND REASSEMBLY INSTRUCTIONS

To remove fan shroud:

- 1. Place the tip of a flat blade screw driver in the location shown in the picture.
- 2. Slightly rotate the screw driver as indicated by the red arrow in the figure. This will release the snap holding the fan shroud in place.
- 3. Repeat steps 1 and 2 on the other side of the fan shroud.

To replace the fan shroud:

- 1. Align the tabs on the fan shroud with the respectful slots on the case top.
- 2. Firmly press down until the fan shroud snaps in place.
- 3. Be careful not to pinch the fan wire between the fan shroud and the case top, this may damage the fan wire.





Copyright © 2014 Castle Creations, Inc. All rights reserved.