

Follow these directions carefully. There are no user serviceable electronic parts inside. You should only open the case to replace the fan. Damage to the circuit board caused by prying the case open is not covered by warranty. **Never, under any circumstances insert anything into the slots that are covered by the labels. Even after you remove the labels!**


To Open the Mamba Monster:

1. Remove the large label that wraps under the bottom of the controller.

2. Hold Monster such that the side with the three motor lead connectors is facing up. Note that there are two slots near the bottom of the case that are part of the case's locking tabs.

3. Insert a small flat bladed screwdriver a short way into the one of the two slots on the case on this side and push the handle of the screwdriver up towards the top of the controller. This will release the plastic snap tab. Repeat for the second tab slot.

4. The case should be partially open. Use your fingers to pull the top away from the bottom.



To Close the Mamba Monster:

1. Connect the fan connector to the port on the bottom of the controller. The label side of the fan should rest against the heat sink when the case is closed.

2. Carefully route the wires to the fan around the capacitors.

3. Close the case. Be very careful when you try to close the Monster case, it is very easy to catch the mounting tabs on the circuit board or components. Monster does need all of those parts to work!

MAMBA MONSTER

castle™